

Wireless Remote Control

RC-80

User Manual



Introduction


The remote control enables you to turn the alarm system on and off before entering the home or after exiting. If there is an emergency, press SOS button on the remote control to trigger the panel. RC-80, compact and portable, is designed to fit on a keychain, in a pocket, or in a purse.

LED Indication

LED flashes once: sends the transmitting signal.

Dim light: Low battery, please replace the battery immediately.

Overview



Specifications

Power supply DC 3V (CR2025 Lithium Battery x 1pc)

Working current ≤ 7mA

Transmitting distance ≤ 80m (in open area)

Radio frequency 315MHz or 433.92MHz (± 75KHz)

Housing material ABS plastic

Operation Condition

Temperature -10°C ~ +55°C

Relative humidity ≤80% (non-condensing)

Dimensions (L x W x H) 58 x 31 x 9.5mm

Usage

Ō	Arm	Press to arm the alarm panel and all of the accessories. (Away Mode)	
6	Disarm	Press to disarm the alarm system.	
(3)	Stay/ Home Mode	Press to arm all sensors except the ones in zone A or Home Mode Zone, sensors in zone A or Home Mode Zone will not activate an alarm.	
sos	Panic	Press to activate a panic alarm and the control panel auto-dials the pre-set phone numbers immediately.	
(a) + (b)	Mute Arm	Press to arm the system in mute.	
(a) + (b)	Mute Disarm	Press to disarm the system in mute.	

Declaration of Conformity

We declare on our sole responsibility that this equipment complies with the essential requirements of the Radio and Telecommunications Terminal Equipment Directive, 1999/5/EC, and that any applicable Essential Test Suite measurements have been performed.

C€2200

CE versions of the Wireless Remote Control (M/N: RC-80) which display the CE symbol on the product label, comply with the essential requirements of the European Radio and Telecommunication Terminal Directive 1999/5/CE.

CHUANGO®							
产品	型 号	RC-80	部件名称		说明书		
设	计	林寿	材	料	80克书写纸		
印刷尺寸		285X210mm	成品尺寸		95X70mm		
エ	艺	折页	版	本	Ver: RC-80-UM-EN-V1.0		

注:

双色、单面印刷 保持产品名称在最上面