



PRISIM

PIR Motion Sensor

Prism is a rechargeable, ultra-low power consuming PIR motion sensor that detects motion within its vicinity, and is able to perform various programmable tasks by communicating with a gateway. Entry detection ensures you receive real time notifications via the Interfree App, protecting your premises at all times.



Easy Setup




Complete Security



IFTTT Interaction



Battery Status



Automation
Appliance Control







Time Scheduled
Operations



Motion Dection



Remote App Control







Product Features

- Australian Standard Certified
- Easy QR Code setup
- Completely secure and stable connectivity
- Can be easily mounted on any wall or ceiling, or placed
 - on a flat surface
- Low power consumption
- Real time battery status
- Real time notifications when battery is low
- Power by a plug or battery (6 month battery life)
- Detects motion using a passive IR sensor
- Setup scenes and automation rules
- **IFTTT**







Technical Specifications

Power Source	3.6V DC Battery OR USB
Battery Type	Polymer Lithium Rechargeable Battery
Battery Life	6 months
Storage Temperature	-20°C to 60°C
Recommended Installation Height	2 -3 M
Working Power	Approx. 50µA
Standby Power	Approx. 1.2µA
Range	8m
Angle Range	120 degree
Communication Protocol	Zigbee








Dimensions

Dimensions	80x80x50mm
Weight	112g



Packaging Details

- 1* 1.5-meter USB Cable
- 1* Mount Bracket
- 1* Prism

1* Mount 3M Tape

1* Instruction Manual





Installation


Step 1: Download the Interfree Application by scanning the QR code below or searching 'Interfree' in the App Store or Google Play.







Download Now










Step 2: Scan the QR Code on the device via the Interfree App.

9:41





ull 🕏 📖



Click on the "+" icon to Add your device to the network


By clicking on "+add" you can add as many devices to Interfree's network

Scan the QR code on device


Note: The Prism should only be switched on after QR code has been scanned for atleast 20 seconds.



Step 3: Once you have scanned the QR code on the sensor for atleast 20 seconds, switch the button ON.



Step 4: Check the indicator light; if the light changes from a slow flash to off, the device has successfully connected to the Zigbee network. The Prism will then appear online in the app.



Step 5: If you scan the device and it doesn't appear online in the app, the device might need to be reset. To reset the device, follow the below instructions.


- A. Open the Interfree App and go into devices.
- B. Tap on 'Gateway'.
- C. Tap the 3 dots in the top right hand corner and select 'Edit'.
- D. Tap 'Advanced Settings'.
- E. Tap on 'Open the Network'.
- F. Hold the device button for 10 seconds to reset.





Mounting the Motion Sensor

The motion sensor should be installed in a location where motion can be adequately detected without causing any false alarms. The best location for a motion sensor is usually in the corner of the room away from any windows. The sensor should be placed approximately 6 to 8 feet off the ground.







The benefits provided by this warranty are in addition to other rights and remedies available to a consumer under Australian consumer laws

1. Who is giving this warranty: Interfree Pty Ltd (ABN 64 632 361 383) (we, us or our) gives this warranty. Our contact details are:

Address: 33 Glenvale Crescent, Mulgrave, Victoria, 3170 Australia

Tel: +61 3 9239 2099

E-mail: warranty@interfree.com.au

- 2.What we will do at our cost: If your Interfree product, or any component of it, malfunctions during the warranty period (see below) due to defective components or workmanship, subject to the terms and conditions set out below, we will, at our option, at our cost, either:
- repair the defective product or component; or
- replace the defective product or component with the same or comparable product or component. If we decide to repair the defective product or component, we will be responsible for the costs of repairs, spare parts and labour. Any defective product or component we decide to replace, and any defective component removed in the course of repairs, will become our property.

We will also pay for the costs of transporting the repaired or replacement product to you, using a means of transport/carrier of our choice.

There are some costs you may have to pay if you make a claim under this warranty: refer to section 6 below.

- 3. Warranty period: The warranty period is one year from the date you purchase your product. Please keep your original invoice or sales docket for the product as proof of purchase. If we carry out any warranty work on your product or any component of it during the warranty period, that will not extend or renew the warranty period for the product, or for any replacement product or components that we provide as part of the warranty work.
- 4.This warranty is not transferable: Only the original purchaser of our product (when purchased new from us, from a retailer or from an installer of the product) may rely on this warranty. It is not transferable to subsequent purchasers of the product.







5.What you need to do to claim under this warranty: If you believe you have a claim under this warranty, please contact us by telephone or email using the contact details set out in section 1 above. If you email us, or leave a telephone message for us, please ensure you leave your name and your email address and/or a daytime telephone number so that we can contact you. Once we have made an initial assessment of your claim, we will let you know what action we will take. We may ask you to send us your original invoice or sales docket for the product as proof of your entitlement to make a claim.

6.Costs you may have to pay: If you make a valid claim under this warranty, you will have to pay the costs of:

- removing (uninstalling) the product. If, by law, your product can only be removed or uninstalled by a qualified and licensed electrician or similar tradesperson, you will need to engage such a person to do so, at your cost;
- transporting or shipping the repaired or replacement product from your premises to us (at our address, as set out in section 1 above). We recommend that, where possible, you use the original packaging a product came in when returning it so as to minimise the risk of damage in transit; and
- re(-)installing the repaired or replacement product. If, by law, the repaired or replacement product can only be (re-)installed by a qualified and licensed electrician or similar tradesperson, you will need to engage such a person to do so, at your cost.
- If, on inspecting your product, we determined that the product was not defective, or that any defect in your product was not covered by this warranty, we would let you know. In that case:
- you will have to pay the costs of transporting or shipping the product back to you, if you wanted the product returned. If you tell us you do not want the product returned, do not agree to pay return transport/shipping costs or you do not make arrangements to collect the product from us within 12 months after we notify you, the product will become our property (without our being required to pay you), and we may dispose of it at our discretion; and
- if you still wanted us to repair your product, you would also be responsible for the costs of the repair, including any applicable spare parts and labour.

We would let you know what the above costs were and seek your authorisation to charge you, before sending the product back to you or effecting any out of warranty repairs.

This does not limit your rights under the Australian Consumer Law.



7. What is not covered by this warranty: This warranty does not cover or apply to any of the following:

- Any consequential or indirect loss, costs or damages or loss of data which you suffer or incur.
- The costs described in section 6 above.
- Deliberate or negligent damage, or damage caused by failing to follow operating instructions.
- Products which have been stored incorrectly, used inappropriately, abused or misused.
- Products which are not specified by us as being suitable for outdoor use having been placed, installed or used outdoors.
- · Damage caused by connection to the wrong voltage, power outages, electrical power surges or improper supply voltage.
- · Any damaged caused by water or immersion of a product in water (except to the extent that the product has been used in a wet environment in accordance with our instructions).
- The failure of any "smart" product to operate, to the extent the failure is caused by the unavailability or inadequacy of, or interruption to, any internet, wi fi or power supply, service or connection which we specify is necessary for the proper operation of the product.
- Damage caused by acts of God (including but not limited to lightning, flood, cyclone, earthquake or unusually severe weather).
- The depletion or replacement of any consumable parts of our products (such as batteries).
- Damage caused by vermin or insects.
- Damage caused during the transportation of products (except where we arranged transport).
- · Cases where no fault or defect in the product or its components could be found by us (in which case, please refer to paragraph 8 below).
- Products which have been installed by non-qualified persons (please note that by law, some of our products can only be installed by a qualified and licensed electrician or similar person).
- · Products or their components which have been repaired or modified by anyone not authorised by us in writing.

8. Your additional legal rights if you are a consumer: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.







Prism

- 33 Glenvale Crescent Mulgrave VIC 3170 Australia
- interfree@interfree.com.au



